

****IMPORTANT****

This is a special DOS bootable CD-ROM or floppy diskette. SeaTools is designed to run from DOS only and is NOT a Windows application.

SeaTools will not run in Windows in a DOS dialog box. Please see the section "Using SeaTools" for more information about booting to this CD or floppy.

Seagate Technology LLC
SeaTools for DOS v1.09

Copyright (c) 2007 by Seagate Technology LLC. All rights reserved.

Welcome to Seagate's SeaTools for DOS Software!

This User Guide file contains important information about SeaTools. Please read this entire file before using this software.

SeaTools for DOS is a comprehensive, easy-to-use diagnostic tool that helps you quickly determine what is preventing you from accessing data on your desktop or notebook computer. It includes several tests that will examine the physical media on your Seagate or Maxtor disc drive and any non-Seagate disc drive.

Table of Contents

-
- 1. Why Use SeaTools?
 - 2. Using SeaTools
 - 3. Error Codes
 - 4. Help Topic: "Bad Sector Found"
 - 5. Troubleshooting
 - 6. Known Limitations
 - 7. System Requirements
 - 8. Seagate Technology Support Services
 - 9. Product Return Procedure
 - 10. Revision History
 - 11. FreeDOS and the GNU Public License
 - 12. USER LICENSE AGREEMENT

=====

1. Why Use SeaTools?

After testing, a large percentage of the drives returned to Seagate for warranty replacement are perfectly good drives with "No Problem Found" (NPF). Returning a drive for warranty service means system downtime and inconvenience for you in packing and returning your drive product. Before you send in a drive, it is in your best interest to determine if a replacement drive is really necessary. This hard disc diagnostic utility will help you make that determination and possibly save you time and money and preserve your data.

Some typical reasons for No Problem Found are:

- * File System Corruption
- * Driver Corruption
- * Broken Master Boot Record
- * Virus and Trojan Attack

- * Spyware, Adware and Keystroke loggers
- * Hardware Conflicts

The Seagate SeaTools software is easy to load and simple to use. The following instructions will help you get the most out of this new software tool. If you have questions about this or any other Seagate software or service products, please contact your system supplier.

=====

2. Using SeaTools

Do not remove the SeaTools diskette while the tests are running. Information from the diskette is used throughout the testing process.

Run Seagate SeaTools

=====

A. Reboot your system

Insert the SeaTools diskette or CD and reboot or power on your computer. The system will boot to the FreeDOS operating system. If your system fails to boot, see the Troubleshooting section #5 later in this file.

B. Select Drives to Test

After SeaTools loads, the screen will number the different storage devices in your system. The first drive detected will be numbered drive 0.

Select the drive you would like to test. Make sure to choose the correct drive! Press the letter D to toggle through the choices or press the actual number of the drive from the listing at the lower section of the screen.

This screen also displays information about the drives such as the Model Number and Serial Number. Seagate model numbers begin with the letters "ST". Seagate serial numbers are alpha numeric and eight characters long.

C. Select the Tests to run

A menu of the possible diagnostic tests is shown. Select the tests that you would like to perform, and select next to continue.

These include:

- S -- SHORT Test
- L -- LONG Test
- C -- Set Capacity
- A -- Acoustic
- Z -- Erase Drive
- H -- Help

When you launch the "SHORT Test" most drives will run Drive Self Test. Drive Self Test (DST) is a thorough diagnostic routine that is built in to the hard drive's firmware. Firmware is the machine language programming the controls the disc drive. DST is completely data safe.

The "SHORT Test" is adequate for most situations. Consider running the "LONG Test" which reads each sector on the drive if you need to run a more comprehensive test.

The "LONG Test" test will take a long time to complete. Because the "LONG Test" reads every sector on the drive, the amount of time required will depend on the speed and capacity of the disc drive. The highest capacity drives often take 2 to 3 hours to complete. At any time, feel free to Cancel the test without harming the drive.

D. Running of the Diagnostics

The SeaTools performs a data-safe test of the selected hard disc drive or device for possible malfunctions. Long tests may be aborted at any time. Press the ESC (escape key) from the keyboard.

During the "LONG Test" only, bad sectors (LBAs) may be detected. They could be part of a data file or even part of the operating system directory structure. Sometimes, problem sectors are empty or not in use. It is important to know that when the sector is bad and unreadable then any data in it is already lost. See section 4 "Help Topic: Bad Sector Found" for more information on this topic.

E. Summary of Results

Upon completion of running the diagnostics, the testing status of each item in the storage explorer. A log for each drive is saved to the RAM drive.

The following conditions may apply:

- Passed
- Passed after Repair (Seagate and Maxtor only)
- Failed
- User Skipped Repairs
- Aborted

"Passed after Repair" is a special condition where bad sectors were detected as unreadable and the user gave permission to SeaTools to attempt to reallocate blank replacement sectors which was successful. The drive is now considered a good drive. A few defects are usually not a cause for concern. For example, there are nearly four hundred million sectors on a 200GB drive. Nonetheless, you should run the LONG Test more often to see if there is a trend of growing defects.

F. Set Capacity

Occasionally, a disc drive may be too large and its size needs to be reduced to a lower capacity. Similarly, a drive with a reduced capacity may need to be reset to its native maximum capacity. Three choices are available under this section:
S - Set 32GB Capacity. A common setting for older systems.
R - Reset to Drive Maximum. Full capacity is restored.
M - Set Manually. Allow you to set a specific size.

G. Erase Drive

ZERO FILL DATA PATTERN WRITING IS A DATA DESTRUCTIVE OPERATION
EQUIVALENT TO ERASING THE DATA OFF THE DRIVE.

Seagate is not responsible for lost user data. Erase Drive is available for Seagate or Maxtor drives only.

Three choices are available under this section:

- Z - Erase Track 0. Use this to clear out an old operating system installation. Very quick.
- A - Zero ALL. This command writes zeros to every sector on the hard drive. This test may take several hours to complete.
- F - Timed Fill. Using the time value set under the T selection, the drive will erase sectors for that time duration.
- T - Set the number of seconds to run. Press T to raise the number.

You must type YES to confirm erasing the drive.

A "Defective drive" can often be revived with a data-destructive zero fill data pattern or a low level format. This is because today's modern disc drives contain thousands of spare sectors which are automatically reallocated if the drive senses difficulty reading or writing. Since SeaTools is read-only (data safe) occasionally a drive with many problem sectors that have not reallocated to a spare sectors can be forced to do so by writing to the sectors. Spare sector reallocation is a normal intelligent drive operation.

See section 4 "Help Topic: Bad Sector Found" for more information on this topic.

Seagate is not responsible for lost user data.

H. Acoustic Test

Sometimes a defective hard drive makes unusual noise. However, often the power supply or CPU fans are mistaken for the hard drive. This test will spin down the drive just like a power management idle condition. If the drive was the source of the noise then the sound will stop. If the noise continues, you can eliminate the hard drive as the source.

I. Viewing a Report

Test results are saved in a log file with a file name based on the drive serial number. This report can be saved to a floppy disk or printed.

**** NOTE **** After exiting SeaTools, if not saved to a floppy, this report will be on the RAM drive until the system is rebooted. If you booted from a CD then the floppy drive is usually B:\. Some systems do not have any floppy diskette drive. Unfortunately, in this case it may be difficult saving the test log files. Some suggestions on using a USB storage device for log files are given in the Troubleshooting section #5 below (topic: CANNOT SAVE or PRINT LOG FILES).

**** NOTE **** If your printer attaches to the computer through the USB port then you will not be able to print in DOS

applications. Printing from SeaTools is supported when the printer is attached to the parallel printer port (LPT1).

I. Quit

To exit the program, select "Quit" from the main menu. Press [CTRL]-[ALT]-[DEL] to reboot, or power off your system.

=====

3. Error Codes

SeaTools for DOS may display a variety of error codes depending on the interface and which test module was running when the error or status occurred. In some situations when the drive is offline running a Drive Self Test, the drive gives its own DST result code.

Drive Self Test (DST) is a thorough diagnostic routine that is built in to the hard drive's firmware. Firmware is the machine language programming the controls the disc drive. DST is completely data safe. SMART (Self Monitoring, Analysis and Reporting Technology) is also built in to the firmware and these errors provide advanced warning about developing problems - such as excessive retries while reading data. A SMART error is a prediction of possible drive failure in the future. Be sure to back up your data regularly.

When a drive is completely non-functional, no make, model or error codes are available.

Beginning with the most common error codes (these codes may display briefly on the screen during the test):

ATA Drive Self Test (DST)

Self-test execution status values:

- 0h The previous self-test routine completed without error or no self-test has ever been run
- 1h The self-test routine was aborted by the host
- 2h The self-test routine was interrupted by the host with a hardware or software reset
- 3h A fatal error or unknown test error occurred while the device was executing its self-test routine and the device was unable to complete the self-test routine.
- 4h The previous self-test completed having a test element that failed and the test element that failed is not known.
- 5h The previous self-test completed having the electrical element of the test failed.
- 6h The previous self-test completed having the servo (and/or seek) test element of the test failed.
- 7h The previous self-test completed having the read element of the test failed. Log file says:

DST - Errors - Status: 07

Off-line data collection status byte values:

01h	Reserved
02h or 82h	Off-line data collection activity was completed without error.
03h	Reserved
04h or 84h	Off-line data collection activity was suspended by an interrupting command from host.
05h or 85h	Off-line data collection activity was aborted by an interrupting command from host.
06h or 86h	Off-line data collection activity was aborted by the device with a fatal error.

=====

4. Help Topic: "Bad Sector Found"

IMPORTANT: Please read and carefully consider all of the following information about your "Bad Sector Found" options.

A bad sector is a small area on the disc drive that is reporting errors and cannot be accessed properly. New bad sectors, sometimes called grown defects, are often caused by some kind of physical damage. If a file or folder uses this sector, then the file is already incomplete or corrupt because the bytes are not readable.

**** NOTE **** The following information applies only to Seagate Technology or Maxtor brand disc drives:

When SeaTools discovers a bad sector through reading, at the end of the scan it displays a list of the bad sectors.

If a sector is in use, then that file is incomplete or corrupt. When a bad sector happens to align with a folder or directory listing structure, then the links to files and sub-folders it manages may be broken. Sectors are often not in use.

You should carefully consider the importance of your data. While the sector is currently unreadable, if the file or folder is important to you then you may need professional recovery services to possibly reclaim the data. In this case, select NO to exit without trying to reallocate blank replacement sectors on the drive.

If you have decided that the file or folder is replaceable, already backed up or just not important to you, then you can tell SeaTools to attempt to overwrite the sector.

By design, modern disc drives maintain spare sectors for reallocation purposes. Usually, sectors become difficult to read long before they become impossible to read. In this situation the actual data bytes in the sector are preserved and transferred to the new spare during a sector reallocation. Similarly, when a disc drive writes data and encounters a problem, the drive firmware retires the problem sector and activates a replacement before giving successful write status.

If you give permission to overwrite a bad sector SeaTools will attempt to write a pattern of zeros to that sector. Usually, this action will assist the disc drive firmware in managing the problem by retiring the problem LBA and activating a spare in its place.

Note: Seagate Technology is not responsible for lost user data.

=====

5. Troubleshooting

----- DRIVE NOT DETECTED

- Understandably, a dead drive cannot communicate with the system or software and will not be detected. A drive with damaged electronics may have the appearance of running but be broken in the ability to communicate with the system. Either of these cases is a failed drive.
- One of the most common reasons for a new drive to not be detected is with the setup of the cables and jumpers, if any. Another common area is with the system BIOS setup. The drive needs to be set to ON in the BIOS, this is especially true when adding a second drive. Be sure to double check if these items are correct.
- Occasionally, a working drive will not be detected by the software. Disc drives attach to the computer through a section of circuitry on the motherboard called a controller. The software is designed to be as up-to-date as possible with known controllers. The drive is not by detectable in this case because of an unknown controller.

SeaTools WILL NOT LOAD

- If when you insert the SeaTools diskette or CD and power on the computer, it does not load SeaTools, the "boot sequence" may be set to boot to the hard disc drive first.

To change the boot sequence to boot from the A: or CD drive first, you must enter the "Setup" or "CMOS Setup" of your computer. Methods for entering the Setup or CMOS Setup vary depending on your computer's make and model, but most methods consist of pressing a key or key sequence during the initial power on boot sequence.

Watch the screen closely during boot up for a message like "Press F2 to enter Setup" or something similar to determine which key or key sequence to press for your computer. Nearly all systems will continue on automatically after a brief period of time if the key is not pressed, so act quickly. You may have only a few seconds to find and press the appropriate key or key sequence.

The most common keys or key sequences to enter setup are:

- [F2]
- [DELETE]
- [F1]
- [CTRL]-[ALT]-[S]
- [CTRL]-[ALT]-[ESC]
- [CTRL]-[ALT]-[ENTER]

NOTE: Some computers that use the "[CTRL]-[ALT]-[___]" sequences must be at a prompt before pressing the keys. If you are unsure about how to enter the setup, see the owner's manual for your computer or seek assistance from your computer manufacturer or the

store where you purchased the computer.

CD ROM WILL NOT BOOT

- Booting to a CD requires that the system BIOS is compatible with the operating system on the CD. In rare cases that seem tied to older system. This indicates an incompatibility with the boot CD. In this situation, the solution is to use the SeaTools boot floppy diskettes instead of the boot CD.

DISKETTE WRITE ERRORS

- The diskette may have a bad sector. If this is the case, create a new SeaTools diskette and run the tests again.

CANNOT SAVE or PRINT LOG FILES

- Many systems no longer have floppy diskette drives. This makes it difficult to save the test results log files. Similarly, systems usually have a USB printer which only prints from Windows. This eliminates printing in DOS.

One possible solution for both of these conditions, only on systems with the right SETUP options, is to attach a USB Storage Device to the system. The SETUP options must support booting to a USB Storage Device. Two examples if systems with USB support:

-->>Dell Optiplex GX270 example

when booting you see in the upper RH corner:

F2 = Setup
F12 = Boot Menu

When you press F2 you can set up the following order:

Hard Disk Drive Sequence
1. USB device
2. System BIOS boot devices
Boot Sequence (BIOS devices)
1. Diskette Drive
2. IDE CD-ROM Device
3. Hard-Disk Drive C:

-->>Dell Inspiron 1150 example:

when booting you see in the upper RH corner:

F2 = Setup
F12 = Boot Menu

When you press F2 on Setup Page 2 you can set up the following order:

***** Boot Order *****
Diskette Drive
USB Storage Device
CD/DVD/CD-RW Drive
Internal HDD

With both of these system examples, the requirement is to put the USB device ahead of the CD which itself should be ahead of the Hard Disk Drive (HDD). Your choice of USB storage device opens a wide range of alternatives. The simplest and least expensive are the USB

Flash Drives. USB external hard drives are another possibility. However in some cases the system BIOS may have compatibility problems with large hard drives and no problems with Flash devices.

Put in the SeaTools bootable CD and plug in a USB storage device. Reboot. With the order set above, the system will attempt to boot from the USB device first but cannot since there is no operating system on it. After that it looks to the BIOS and sees the IDE CD-ROM Device where it boots into SeaTools. If the USB device was detected it will be mounted as a (non-booting, assuming FAT) C: where we can save the log files.

After you run SeaTools, exit and copy *.log to C: and you have just saved the logs without using a floppy. If your RAM drive is shown as C: then the SETUP does not support USB storage in DOS. The file system on the USB device must be either FAT16 or FAT32. DOS does not recognize NTFS.

IF YOU CALL

- If you call to report problems please provide as much information as possible. If you can, please provide the following details:

When does the problem occur?
 On the boot up of the diagnostic operating system?
 During the hard disc drive tests?
 After exiting SeaTools?

- Can the problem be recreated? If so, please outline the steps necessary to recreate it.
- What is your system configuration? List the details about your system as tested. Such as:
 - Make, model, processor and system memory
 - Hard disc drives (internal and external) connected to the system, including make, model, size, and type
 - Make and model of hard disc drive controllers
 - Make and model of the video adapter
 - Additional adapter cards, including sound and multimedia
 - Peripherals attached (mouse, tape backup, printer, etc).

=====

6. Known Limitations

- * SeaTools may not find or access hard disc drives when CMOS is set to "none" for those drives.
- * SeaTools Desktop cannot find a drive that is completely non-functional. No make, model or error codes are available. If the drive is under warranty, you can contact your system supplier.

Check <http://www.seagate.com> often for new and updated versions of SeaTools for DOS software as well as updates to the "Frequently Asked Questions" (FAQ's) list. Seagate will continue to add new features, functions and capabilities to this software.

=====

7. System Requirements

-
- * IBM-compatible PC with a Pentium or greater processor
 - * VGA 640 x 480 or greater graphics capability
 - * 64 megabytes of RAM
 - * 1.44 megabyte floppy disk drive or Bootable CD

8. Seagate Technology Support Services

Seagate Technology Support Services

Online Services

Internet

www.seagate.com for information about Seagate products and services. Worldwide support is available 24 hours daily by e-mail for your questions.

Technical Support:

http://www.seagate.com/www/en-us/about/contact_us
or email to DiscSupport@Seagate.com

SEAGATE SERVICE CENTERS

Presales Support

Our Presales Support staff can help you determine which Seagate products are best suited for your specific application or computer system, as well as drive availability and compatibility.

Technical Support

If you need help installing your drive, consult your system's documentation or contact the dealer's support services department for assistance specific to your system. Seagate technical support is also available to assist you online at support.seagate.com or through one of our call centers. Have your system configuration information and your drive's "ST" model number available.

SeaTDD (+1-405-324-3655) is a telecommunications device for the deaf (TDD). You can send questions or comments 24 hours daily and exchange messages with a technical support specialist during normal business hours for the technical support call center in your region.

CUSTOMER SERVICE OPERATIONS

Warranty Service

Seagate offers worldwide customer support for Seagate drives. Seagate distributors, OEMs and other direct customers should contact their Seagate service center representative for warranty-related issues. Resellers or end users of drive products should contact their place of purchase or one of the Seagate warranty service centers for assistance. Have your drive's "ST" model number and serial number available.

Data Recovery Services

Seagate offers data recovery services for all formats and all brands of storage media. Our Data Recovery Services labs are currently located in North America and Europe. To get a free quick quote or speak with a case management representative, call 1-800-475-0143. Additional information, including an online request form and data loss prevention resources, is available at www.datarecovery.seagate.com.

USA/Canada/Latin America Support Services

Americas 1-800-SEAGATE +1-405-324-4700 +1-405-324-3339

Worldwide Support Services

For the most current list of telephone numbers please see the Contact Us section on www.seagate.com.

Contact Information Rev 8.1, 10-Jan-2006

SeaTools for DOS is a product of Seagate, a leading provider of technology and products enabling people to store, access, and manage information. Seagate is committed to providing best-in-class products to help people get their information when, where and how they want it.

The Company is recognized as the world's largest manufacturer of disc drives, magnetic discs and read-write heads. Founded in 1979, Seagate can be found around the globe and on the World Wide Web at www.seagate.com.

=====

9. Product Return Procedure

Service by Seagate

-
- A. Seagate Disc Return Procedure
- B. Shipping and Handling Information - Packaging Instructions
- C. Seagate Approved Packaging
- D. Limited Warranty
- E. Service Warranty Terms

A. Seagate Disc Drive Return Procedure

Seagate offers comprehensive worldwide customer support for all Seagate disc drives both online and through our regional Seagate Customer Service Centers and Authorized Service Providers (see "Seagate Technology Support Services" section, above). Drive return procedures can vary by geographical location and are subject to current International Trade Regulations.

1. Before you return a disc for warranty service, verify whether a replacement drive is necessary to solve the problem you are experiencing. If so, contact your place of purchase; if they have an exchange policy, it may be your most convenient solution.
2. Read the appropriate Seagate Warranty Statement for new or replacement products (see "Service Warranty Terms" section, below).
3. Know your Seagate product model number and serial number. See the label on the top of the drive.

4. Verify the warranty status of the drive you wish to return. If the product is still under warranty, obtain an RMA (step 5). If the warranty is expired, contact a local service facility, a Seagate Service Center Representative, or an Authorized Service Provider. If Seagate records indicate that the warranty is expired and you believe this is incorrect, contact your place of purchase or a Seagate Service Center Representative.
5. Obtain an RMA. To obtain an RMA online, use the Warranty Validation application at www.seagate.com/support. It will lead you into the RMA request application. To obtain an RMA by phone or fax, contact an Authorized Service Center (see "Seagate Technology Support Services" section above).
6. Obtain a "ship to" address. Service Centers are located throughout the world. The ship to address of the facility nearest you will be included with the RMA.
7. Package and return the drive. IMPROPER PACKAGING WILL VOID THE WARRANTY. Be sure to read the Shipping and Handling Information (below). Your original drive will NOT be returned to you, so be sure to backup any data you wish to keep and return only the bare drive. If you are unable to retrieve needed data, you may want to consider data recovery services.

Once Seagate Technology receives your drive for service, Seagate will ship you a replacement drive. You may check the status of your replacement drive RMA shipment online or by contacting a Seagate Service Center Representative to obtain that information.

B. Shipping and Handling Information - Packaging Instructions

1. When you return a drive for replacement, all data and software will be lost. The replacement drive will be low-level formatted. If you need the data on the drive and do not have a backup copy, you may want to consider data recovery services before shipping the drive to Seagate for replacement.
2. Remove all accessories or spare parts and return only the bare drive! Accessories include, but are not limited to, side rails, manuals, removable media, cables, mounting brackets, face plates, and controller cards. Accessories will not be returned.
3. Enclose the drive in an anti-static container. If packaging more than one drive, use a separate bag for each drive.
4. Secure the drive in Seagate approved packaging. Use 2-inch thick foam rubber in a corrugated box. Multiple drives in a single box should be packaged with foam rubber between each drive. Do NOT use foam packing pellets, bubble wrap, or newspaper. (See Seagate Approved Packaging section, below.)
5. Write the RMA number on the outside of each box.
6. A shipping address will be given to you along with the RMA number. Ship the drive to the address provided using the carrier of your choice. You should choose a carrier with the ability to trace the shipment. Seagate Technology will not be responsible for shipments for which the carrier cannot provide proof of delivery.

C. Seagate Approved Packaging

Shipping a drive in an unapproved container voids the warranty. Any product returned to Seagate must be properly packaged in the original box or a Seagate-approved container to prevent physical and electrical damage while in transit. FAILURE TO PROPERLY PACKAGE THE DRIVE WILL VOID THE WARRANTY.

What is Seagate Approved Packaging?

We recommend you ship your drive in its original box and packing materials, which you should always keep for storing and shipping purposes. If you do not have your original packaging materials, use 2-inch thick foam rubber in a corrugated box. Multiple drives in a single box should be packaged with foam rubber between each drive. Do NOT use foam packing pellets, bubble wrap, or newspaper.

Where can I get Seagate Approved Packaging?

Seagate does not separately sell packaging materials. While Seagate does not endorse any one third party vendor, companies that provide packaging materials can be found at:

Western Industries - For additional information, see
<https://www.wicokc.com/orderform/seagate.html>

SiongBee - For additional information, see
<https://www.siongbee.com/sforder.nsf>

Disclaimer: All packaging vendors mentioned in this message are independent of Seagate Technology LLC; Seagate makes no warranty, implied or otherwise, regarding the performance or reliability of these companies or their products. This information is provided, as is, solely for your information. To obtain product specifications and warranty information, please contact the respective vendor directly.

D. Limited Drive Warranty ("Products")

Beginning on the date of shipment to its direct customer and continuing for the published warranty period, Seagate represents that the Products are new or, if they contain remanufactured or used components, are the equivalent of new in performance and reliability and warrants that each Product failing to function properly under normal use, due to a defect in materials or workmanship or due to nonconformance to the published specifications, will be repaired or exchanged, at Seagate's option and expense. Customer should obtain a Return Material Authorization ("RMA") number from their point of purchase or from Seagate prior to returning the nonconforming Product freight prepaid. Seagate will pay for transporting the repaired or exchanged Product to Customer. Repaired or exchanged Product will be warranted for a period of ninety (90) days for Disc Products and six (6) months for Tape Products from the date of shipment by Seagate, or the remainder of the original warranty, whichever is the longer. This Limited Warranty extends to Seagate's direct customer only and is not assignable or transferable. Seagate makes no representation, warranty or guaranty, express or implied regarding the Products except its standard form of limited warranty ("Limited Warranty"). Seagate may in its sole discretion modify its Limited Warranty at any time and from time to time.

DRIVE PRODUCT WARRANTY DISCLAIMER

EXCEPT AS SET FORTH IN WRITING IN THE LIMITED WARRANTY, SEAGATE MAKES NO PERFORMANCE REPRESENTATIONS, WARRANTIES, OR GUARANTEES, EITHER EXPRESS OR IMPLIED, ORAL OR WRITTEN, WITH RESPECT TO ITS PRODUCTS, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (A) OF MERCHANTABILITY, (B) OF FITNESS FOR A PARTICULAR PURPOSE, OR (C) ARISING FROM COURSE OF PERFORMANCE, COURSE OF DEALING, OR USAGE OF TRADE.

IN NO EVENT SHALL SEAGATE BE LIABLE FOR COSTS OF PROCUREMENT OF SUBSTITUTE GOODS BY ANYONE OR FOR LOSS OF DATA, NOR WILL IT BE LIABLE FOR INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, OR OTHER DAMAGES ARISING OUT OF THE PURCHASE, USE OR PERFORMANCE OF THE PRODUCT, AND WHETHER OR NOT IT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE FOREGOING ALLOCATION OF RISK IS REFLECTED IN THE PRICE OF THE PRODUCT.

E. Repair Warranty Terms

All Seagate repaired disc products are warranted for 90 days or the balance of your original warranty, whichever is greater. All Seagate repaired tape products are warranted for six months or the balance of your original warranty, whichever is greater. Customer shall be responsible for saving or backing up data contained in any Product returned to Seagate for in-warranty or out-of-warranty repairs or service.

DISCLAIMER: SEAGATE SHALL HAVE NO RESPONSIBILITY FOR DATA AND SHALL HAVE NO LIABILITY ARISING OUT OF ANY DAMAGE TO OR LOSS OF DATA WHILE THE PRODUCT IS IN SEAGATE'S POSSESSION.

THANK YOU

=====

10. Revision History

v1.08	30-Jan-2007	Initial public release SeaTools for DOS.
v1.09	28-Feb-2007	Added Help option to main menu.

=====

11. FreeDOS and the GNU Public License

This software uses the FreeDOS kernel, an open source product distributed under the terms of the GNU Public License (GPL). You can obtain the source code to the FreeDOS kernel used for this product at <http://www.seagate.com/support/seatools/freedos/kernel.zip> You can obtain the most recent copy at the FreeDOS we site at <http://www.freedos.org>.

=====

12. USER LICENSE AGREEMENT

THIS IS A LEGAL AGREEMENT BETWEEN YOU ("CUSTOMER") AND SEAGATE TECHNOLOGY, LLC ("SEAGATE"), A DELAWARE LIMITED LIABILITY COMPANY WITH ITS PRIMARY PLACE OF BUSINESS LOCATED AT 920 DISC DRIVE, SCOTTS VALLEY, CA 95066. PLEASE READ THIS AGREEMENT CAREFULLY. BY CLICKING THE "I ACCEPT" BUTTON, YOU INDICATE YOUR AGREEMENT TO BE BOUND BY ALL

OF THE TERMS AND CONDITIONS OF THIS AGREEMENT. DO NOT SELECT "I ACCEPT," DOWNLOAD OR COPY THE SOFTWARE UNTIL YOU HAVE CAREFULLY READ, UNDERSTOOD AND AGREED TO THE FOLLOWING TERMS AND CONDITIONS. IF YOU DO NOT WISH TO AGREE TO THESE TERMS AND CONDITIONS CLICK "I DO NOT ACCEPT" AND YOU WILL NOT BE PERMITTED TO DOWNLOAD THE SOFTWARE.

1. License Grant. Seagate grants to Customer a worldwide, nonexclusive, nontransferable, royalty free license to use the

SeaTools for DOS

("Software") for use with Seagate disc drives.

EXCEPT AS EXPRESSLY AUTHORIZED ABOVE, CUSTOMER WILL NOT: COPY, IN WHOLE OR IN PART, SOFTWARE OR DOCUMENTATION; MODIFY THE SOFTWARE; REVERSE COMPILE, REVERSE ENGINEER, DISASSEMBLE OR REVERSE ASSEMBLE ALL OR ANY PORTION OF THE SOFTWARE; RENT, LEASE, LICENSE, SUBLICENSE, DISTRIBUTE, OR SELL THE SOFTWARE; OR CREATE DERIVATIVE WORKS OF THE SOFTWARE. Customer obtains no rights in the software except those given in this limited license.

2. Ownership. The Software and any related documentation is owned by Seagate and/or its suppliers. The Software is protected by United States and international copyright laws. Customer will not remove, alter or destroy any copyright, proprietary or confidential notices placed on the Software or any related documentation. Customer agrees that aspects of the Software, including the specific design and structure of individual programs, constitute trade secrets and/or copyrighted material of Seagate. Customer agrees not to disclose, provide, or otherwise make available such trade secrets or copyrighted material in any form to any third party without the prior written consent of Seagate. Customer agrees to implement reasonable security measures to protect such trade secrets and copyrighted material. This section will survive any termination of this agreement.

3. NO WARRANTIES. THE SOFTWARE AND ANY RELATED DOCUMENTATION ARE PROVIDED TO YOU "AS IS." SEAGATE MAKES NO WARRANTIES, EXPRESS OR IMPLIED, AND EXPRESSLY DISCLAIMS ALL REPRESENTATIONS, ORAL OR WRITTEN, TERMS, CONDITIONS, AND WARRANTIES, INCLUDING BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NONINFRINGEMENT. WITHOUT LIMITING THE ABOVE YOU ACCEPT THAT THE SOFTWARE MAY NOT MEET YOUR REQUIREMENTS, OPERATE ERROR FREE, OR IDENTIFY ANY OR ALL ERRORS OR PROBLEMS, OR DO SO ACCURATELY. This Agreement does not affect any statutory rights you may have as a consumer.

4. LIMITATION ON LIABILITY. IN NO EVENT SHALL SEAGATE BE LIABLE TO YOU, YOUR CUSTOMERS, OR OTHER USERS, FOR ANY DIRECT CONSEQUENTIAL, SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OF ANY KIND ARISING OUT OF THE LICENSE OF, USE OF, OR INABILITY TO USE THE SOFTWARE, INCLUDING WITHOUT LIMITATION DATA LOSS, EVEN IF SEAGATE OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT SHALL SEAGATE'S LIABILITY EXCEED THE LICENSE FEE PAID BY YOU OR \$1. THIS LIMITATION OF LIABILITY AND RISK IS REFLECTED IN THE PRICE OF THE SOFTWARE. SOME JURISDICTIONS DO NOT ALLOW FOR LIMITATIONS ON CONSEQUENTIAL DAMAGES.

5. Term. Seagate may immediately terminate this Agreement and the license it grants at any time or if Customer fails to comply with any material term or condition. Upon such termination Customer must

immediately cease using the Software and must follow Seagate's instructions regarding return of the Software. ALL DISCLAIMERS HEREIN WILL SURVIVE TERMINATION.

6. Access Outside or within the United States. Activities under this Agreement may be subject to U.S. governmental regulations, including but not limited to regulations applicable to the import and export of encryption and decryption software, technical information, technical data, or products made using technical information or technical data or components. Customer will comply with all applicable export, re-export and foreign policy controls and restrictions imposed by the United States. Customer will take necessary actions and precautions to ensure that it complies with all such laws or regulations. This section will survive any termination of this agreement.

7. Miscellaneous. In the event that a Software Development Agreement (SDA) exists between the parties, the provisions of the SDA will control any conflicting provisions of this Agreement, unless otherwise agreed to in writing. The parties disclaim the application of the United Nations Convention on the International Sale of Goods. This Agreement will be governed by the laws of the State of California and the United States of America, without regard to conflict of law principles. The terms of this Agreement are severable. If any term is unenforceable for any reason, that term will be enforced to the fullest extent possible, and the Agreement will remain in effect.

version 1.1 [Rev.26 April 2004]

(C) 2007 Seagate Technology LLC. End of User License Agreement.

--EOF: README.TXT--